

Master data

## Appliances properties: Supra S.A. - 254 D - Marke Worldkamin

Date of entry Feb 26, 2008
Manufacturer Supra S.A.
Model 254 D

Product code Marke Worldkamin

Nominal heat output [kW] 1

Continuous burning appliance

Type test standard DIN 18895
Year of testing 1990

Test laboratory RWE Rheinbraun AG

Number of test laboratory 4.1

Number of test report RBW-VF 1-Hn 41/89

Flue gas values

	Wood	
Flue gas mass flow [g/s]	12	
Flue gas mass flow [g/s]	300	
Necessary flue draught [Pa]	12	

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)



Connectivity to the central heating system



On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

General technical approval for room sealed operation

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup>A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Norm: Inset appliances (with closed firedoor) D - 1.BImSchV According to the transitional rule §26 the appliance can be used until 31.12.2020 A - Austrian regulation referred to Art 15a B-VG CH - Swiss clean air act F - Crédit d'impôt à la transition énergétique

Evaluation of emission data and efficiency Wood

Evaluation of emission data and efficiency Lignite briquettes	
Norm : Inset appliances (with closed firedoor)	Evaluation
D - 1.BlmSchV	According to the transitional rule §26 the appliance can be used until 31.12.2020
A - Austrian regulation referred to Art 15a B-VG	_
CH - Swiss clean air act	ļ.



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information