

Master data

Appliances properties: Max Blank GmbH - Orange SP kombi

Date of entry	Jul 23, 2019	
Manufacturer	Max Blank GmbH	
Model	Orange SP kombi	
Nominal heat output [kW]	5.8	
Declared nominal space heating output [kW]	5.8	
Partial load [kW]	3	
Part load space heating output [kW]	3	
Continuous burning appliance	_	

Type test standard DIN EN 13240

Year of testing 2015

Test laboratory DBI-Gastechnisches Institut gGmbH Freiberg

Number of test laboratory 12

Number of test report DBI F 15/04/0324

Flue	ass	val	LIES

	Wood	
Flue gas mass flow [g/s]	5.28	
Flue gas mass flow [g/s]	255	
Necessary flue draught [Pa]	12	

Further important characteristics of the appliance

Suitability for installation to a shared flue¹⁾



Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

^{*} A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Evaluation of emission data and efficiency Wood

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation	
D - 1.BlmSchV	Stufe 2	
A - Austrian regulation referred to Art 15a B-VG	2015	
CH - Swiss clean air act	✓	
DK - Danish regulation for air pollution from wood burners	✓	
F - Crédit d'impôt à la transition énergétique	7☆	

Evaluation of emission data and efficiency Lignite briquettes

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation
D - 1.BlmSchV	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information