

## Appliances properties: Olsberg GmbH - Olsberg - Bodö - 23/178

| Master data                  |                        |   |
|------------------------------|------------------------|---|
| Date of entry                | Apr 6, 2011            | - |
| Manufacturer                 | Olsberg GmbH - Olsberg |   |
| Model                        | Bodö                   |   |
| Product code                 | 23/178                 |   |
| Nominal heat output [kW]     | 8                      | 1 |
| Continuous burning appliance | Mart In-               | 1 |
| Type test standard           | DIN 18891              |   |
| Year of testing              | 1999                   |   |

Further important characteristics of the appliance

Suitability for installation to a shared flue<sup>1)</sup>

Connectivity to the central heating system

General technical approval for room sealed operation

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

\* A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Evaluation of emission data and efficiency Wood

| Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing | Evaluation  |
|---|---|
| D - 1.BlmSchV   | According to the transitional rule §26 the appliance can be used until 31.12.2024 |
| F - Crédit d'impôt à la transition énergétique                              | !   |

| Evaluation of emission data and efficiency Lignite briquettes               |            |
|---|------------|
| Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing | Evaluation |
|   |            |

## D - 1.BImSchV

According to the transitional rule §26 the appliance can be used until 31.12.2024

Emission evaluation legend

| Stufe 2      | Compliant with the requirements of the 2nd stage of the 1.BImSchV (only for Germany)  |  |  |
|--------------|---|--|--|
| Stufe 1      | Compliant with the requirements of the 1st stage of the 1.BImSchV (only for Germany)  |  |  |
| 2015         | Compliant with the requirements of the Austrian Agreement pursuant to Art. 15a B-VG from 2015 (applies only to Austria)                                   |  |  |
| 7☆           | Compliant with the requirements for the "Crédit d'impôt" promotion in France, the fireplace complies with the classification 7* of the Flamme Verte Label |  |  |
| 6☆           | Compliant with the requirements for the "Crédit d'impôt" promotion in France, the fireplace complies with the classification 6* of the Flamme Verte Label |  |  |
| 5☆           | Compliant with the requirements for the "Crédit d'impôt" promotion in France, the fireplace complies with the classification 5* of the Flamme Verte Label |  |  |
| *            | Compliant with the requirements of the 1 star stage in Italy.   |  |  |
| <b>↓</b>     | Compliant with the requirements of the 2 star stage in Italy.   |  |  |
| ***          | Compliant with the requirements of the 3 star stage in Italy.   |  |  |
| ***          | Compliant with the requirements of the 4 star stage in Italy.   |  |  |
| ****         | Compliant with the requirements of the 5 star stage in Italy.   |  |  |
|              | Fulfils the requirements  |  |  |
| $\checkmark$ | Complies with requirements of the transition ruling (1.BImSchV)   |  |  |
|              | Requirements are not fulfilled  |  |  |
| _            | No information/unknown  |  |  |
| !            | No measuring values are available for this fuel, operation with this fuel is not permitted  |  |  |
| No syr       | No symbol means that there are no requirements.   |  |  |

Here you will find further information