

Appliances properties: Olsberg GmbH - Olsberg - Petacas Compact - 23/775

Master data

Date of entry

Manufacturer

Model

Product code

Nominal heat output [kW]

Declared nominal space heating output [kW]

Continuous burning appliance

Type test standard

Year of testing

Test laboratory

Number of test laboratory

Number of test report

May 24, 2018

Olsberg GmbH - Olsberg

Petacas Compact

23/775

5

5

DIN EN 13240

2017

Feuerstättenprüfstelle Kahl GmbH

28

FK 40 17 513



Flue gas values

	Wood	Coal
Flue gas mass flow [g/s]	4.16	6.12
Flue gas mass flow [g/s]	300	294
Necessary flue draught [Pa]	12	12

Further important characteristics of the appliance

Suitability for installation to a shared flue¹⁾



Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

^{*}A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Evaluation of emission data and efficiency Wood

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation
D - 1.BlmSchV	Stufe 2
A - Austrian regulation referred to Art 15a B-VG	2015
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	✓
F - Crédit d'impôt à la transition énergétique	√ 7☆

Evaluation of emission data and efficiency Lignite briquettes

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing

Evaluation

D - 1.BlmSchV

Stufe 2



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information