

Appliances properties: HWAM A/S - HWAM 4540c IHS

Master data	
Date of entry Jul 18, 2017	
Manufacturer HWAM A/S	
Model HWAM 4540c IHS	
Nominal heat output [kW] 5.1	
Continuous burning appliance	
Type test standard DIN EN 13240	
Year of testing 2016	
Test laboratory RRF Rhein-Ruhr-Feuerstätte	enprüfstelle GmbH
Number of test laboratory 2	
Number of test report RRF - 40 16 4221	
Flue gas values	
Flue gas values	Wood
Flue gas values Flue gas mass flow [g/s]	Wood 4
Flue gas mass flow [g/s]	4
Flue gas mass flow [g/s] Flue gas mass flow [g/s]	4 324
Flue gas mass flow [g/s] Flue gas mass flow [g/s]	4 324
Flue gas mass flow [g/s] Flue gas mass flow [g/s] Necessary flue draught [Pa]	4 324
Flue gas mass flow [g/s] Flue gas mass flow [g/s] Necessary flue draught [Pa]	4 324

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

^{*} A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Evaluation of emission data and efficiency Wood

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation
D - 1.BlmSchV	Stufe 2
A - Austrian regulation referred to Art 15a B-VG	2015
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	✓
F - Crédit d'impôt à la transition énergétique	7☆

Evaluation of emission data and efficiency Lignite briquettes

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation
D - 1.BlmSchV	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information