

## Appliances properties: Spartherm Feuerungstechnik GmbH - Speedy 1V 51 14,5kW E - A1

Master data Date of entry Oct 17, 2013 Manufacturer Spartherm Feuerungstechnik GmbH Model Speedy 1V 51 14,5kW E - A1 Nominal heat output [kW] 14.5 Continuous burning appliance Type test standard **DIN EN 13229** 2013 Year of testing **Test laboratory** RRF Rhein-Ruhr-Feuerstättenprüfstelle GmbH Number of test laboratory Number of test report RRF - 29 13 3296 Flue gas values Wood Flue gas mass flow [g/s] 10.85 Flue gas mass flow [g/s] 346 Necessary flue draught [Pa] 12 Further important characteristics of the appliance

Suitability for installation to a shared flue<sup>1)</sup>

Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup>A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Evaluation of emission data and efficiency Wood

EU-Inset appliance according to EN13229	Evaluation
EU - Regulation (EU) 2015/1185 (Ecodesign)	<b>*</b>
D - 1.BlmSchV	Stufe 2
A - Austrian regulation referred to Art 15a B-VG	<b>*</b>
CH - Swiss clean air act	<b>*</b>
DK - Danish regulation for air pollution from wood burners	<b>*</b>
F - Crédit d'impôt à la transition énergétique	7☆
I - Italian Decree No. 186	南南南

## Evaluation of emission data and efficiency Lignite briquettes

Norm : Inset appliances (with closed firedoor)	Evaluation
D - 1.BlmSchV	I



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information