

Appliances properties: Supra S.A. - Emeraude 1830D - Marke Supra

Master data Date of entry Feb 26, 2008 Manufacturer Supra S.A. Model Emeraude 1830D Product code Marke Supra Nominal heat output [kW] Continuous burning appliance DIN 18895 Type test standard Year of testing 2005 RWE Rheinbraun AG **Test laboratory** Number of test laboratory 4.1 Number of test report RB BF1-Hn 790

Flue	gas	values
1 140	guo	valuoo

Wo	ood
Flue gas mass flow [g/s]	12
Flue gas mass flow [g/s]	300
Necessary flue draught [Pa]	12

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)



Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

^{*}A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Norm: Inset appliances (with closed firedoor) D - 1.BImSchV According to the transitional rule §26 the appliance can be used until 31.12.2024 A - Austrian regulation referred to Art 15a B-VG CH - Swiss clean air act F - Crédit d'impôt à la transition énergétique

Evaluation of emission data and efficiency Wood

Evaluation of emission data and efficiency Lignite briquettes		
Norm : Inset appliances (with closed firedoor)	Evaluation	
D - 1.BImSchV	According to the transitional rule §26 the appliance can be used until 31.12.2024	
A - Austrian regulation referred to Art 15a B-VG	_	
CH - Swiss clean air act	!	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information